



SIP INDUSTRIAL 04381 QTA24/10 SIP QT Air Oil Less Air Compressors User Manual

[Home](#) » [SIP INDUSTRIAL](#) » SIP INDUSTRIAL 04381 QTA24/10 SIP QT Air Oil Less Air Compressors User Manual



SIP INDUSTRIAL

04381 QTA24/10 SIP QT Air Oil Less Air Compressors
User Manual





Read and understand this operator's manual thoroughly before using the product. It contains important information for your safety as well as operating and maintenance advice.

Contents


- 1 Safety Guidelines
- 2 Key Parts Diagram
- 3 Assembly
- 4 Operating Instructions
- 5 Maintenance
- 6 Troubleshooting
- 7 Technical Specification
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts

Safety Guidelines

Important Safety Information

The manufacturer cannot possibly anticipate every possible circumstance that might involve a hazard. The warnings in this manual, and the tags and decals affixed to the unit are, therefore, not all-inclusive. If you use a procedure, work method, or operating technique that the manufacturer does not specifically recommend, you must satisfy yourself that it is safe for you and others. You must also make sure that the procedure, work method, or operating technique that you choose does not render the compressor unsafe.

Safety Symbols and Meanings



The safety alert symbol indicates a potential hazard to personal injury. A signal word (DANGER, WARNING, or CAUTION) is used with the alert symbol to designate a degree or level of hazard seriousness. A safety symbol may be used to represent the type of hazard. The signal word NOTICE is used to address practices not related to personal injury.

DANGER indicates a hazard which, if not avoided, will result in death or serious injury.



WARNING indicates a hazard which, if not avoided, could result in death or serious injury.



CAUTION indicates a hazard which, if not avoided, could result in minor or moderate injury.

Notice address practices not related to personal injury.

DO NOT OPERATE THIS UNIT UNTIL YOU READ AND UNDERSTAND THIS INSTRUCTION MANUAL FOR SAFETY, OPERATION, AND MAINTENANCE INSTRUCTIONS.



WARNING



Risk of fire caused by sparks from motor and pressure switch could result in death or serious injury. Do not operate compressor near flammable gas or vapor. Never store flammable liquids or gases in vicinity of compressor.



High pressure air could result in death or serious injury. Never operate above maximum operating pressure of the spray gun or tool. Drain water from tank after each use.

Do not weld or repair tank.

Do not operate with pressure switch or safety valve set above maximum allowable working pressure.



Hot compressor surfaces could result in serious injury. Allow compressor to cool before touching.



Inhalation hazard. Using compressor to supply breathing air could result in death or serious injury. Do not use compressor to supply breathing air.



Risk of fire could result in death or serious injury.

Do not spray flammable materials in vicinity of any flame or ignition sources including the compressor unit.

Do not restrict compressor ventilation openings or place objects against or on top of compressor. Operate compressor only in a clean, dry, well ventilated area.

Do not operate unattended. Always turn off and unplug unit when not in use.



Risk of serious eye injury. Always wear CE approved safety glasses when using air compressor. Do not spray any part of the body.



Always wear hearing protection when using an air compressor. Failure to do so may result in hearing loss.



Shock risk could result in death or serious injury. Only connect compressor to a properly grounded receptacle. **KEEP CHILDREN AWAY FROM THE AIR COMPRESSOR AT ALL TIMES.**




Dust can be created when cutting, sanding, drilling or grinding materials such as wood, paint, metal, concrete, cement, or other masonry. To reduce your exposure to these chemicals, work in a well ventilated area and **ALWAYS** wear approved safety equipment.



This air compressor is supposed to be stored in ambient temperature condition : centigrade temperature from 20 to 30°C.

Key Parts Diagram



Item	Description	Item	Description
A	Motor & Pump Assembly	F	Quick Connector Air Outlet
B	Air Receiver 24L or 50L	G	Air Tank Ball Valve
C	Air Pressure Regulator	H	Pressure Relief Safety Valve
D	Tank Pressure Gauge	I	ON / OFF Pressure Switch
E	Regulated Pressure Gauge	J	Mains Lead

A. ELECTRIC MOTOR: The motor is used to power the pump. It contains a thermal overload protector. If the motor overheats for any reason, the thermal overload protector will shut it down in order to prevent the motor from being damaged.

AIR COMPRESSOR PUMP: The pump is used to compress the air and discharge it into the tank via the piston moving up and down in the cylinder.

B. AIR RECEIVER: The Air Tank / Receiver is used to store the compressed air.

C. TANK PRESSURE GAUGE: The gauge is used to measure the stored air pressure level inside the tank. It is not adjustable by the operator and does not indicate line / outlet pressure.

D. AIR PRESSURE REGULATOR: The regulator is used to adjust line / outlet pressure to the tool you are using. Turn the knob clockwise to increase pressure and counterclockwise to decrease pressure.

WARNING



Never exceed the maximum working pressure of the tool.

E. REGULATED PRESSURE GAUGE: The gauge is used to measure the regulated outlet pressure.

F. QUICK COUPLER: The air compressor features a quick coupler for air outlet connecting ease.

G. AIR TANK BALL VALVE: The ball valve is used to remove moisture / condensate from the air tank after the unit is shut off.



WARNING

Never attempt to open the drain valve when the tank pressure is more than 10 PSI.


H. PRESSURE RELIEF SAFETY VALVE: The valve is used to prevent the compressor from over pressure. If the pressure reaches the preset level, it will automatically pop open.

I. ON/OFF – PRESSURE SWITCH: This switch turns on the compressor and is operated manually. The compressor will produce air and shut off at the “Cut-Off “pressure. When air is drawn by an air tool the compressor will automatically start to pump once the “Cut-In” pressure has been reached. ALWAYS set this switch to OFF when the compressor is not being used and before unplugging the compressor.

J. MAINS LEAD: This compressor is for use with a 230 Volt UK domestic socket and should be grounded / Earthed.

Make sure that the product is connected to an outlet that has the same configuration as the plug (see Figure 1). If an extension lead is used, make sure the cable size is sufficient as to be able to take the current of the compressor

Check with a licensed electrician if the grounding instructions are not understood or there is doubt as to whether the product is properly grounded. Do not modify the plug provided. If it will not fit the outlet, have the proper outlet installed by a licensed electrician.



DANGER Improper installation of the grounding plug will result in a risk of electric shock. If repair or replacement of the cord or plug is necessary, consult a qualified electrician.

Assembly

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 5 minutes

Tools Required for Assembly (not included):



ASSEMBLY INSTRUCTIONS

1. Removable Handle Assembly

- Insert handle (K) into the axed sleeves. Align the tapped holes (K1) with the holes on the sleeve.
- Fasten the handle to the sleeve using the screws (AA).

Hardware Used

AA M6 × 14 Screw



2. Wheel Assembly



- Insert the bolt (BB) through one of the wheels (L).
- Insert the bolt (BB) through the bracket on the bottom of the tank assembly, spring washer (CC) and tighten the nut (DD). Repeat this step for the second wheel.
- Once assembled, roll the air compressor to test the operation of the wheels. Periodically check to ensure that wheel and the hardware is secure.

Hardware Used

BB M10 Bolt

CC x10 Spring Washer

DD M10 Nut



3. Air Filter Installation

Screw the air filter assembly into the pump cylinder head (see image Pg.3).



Operating Instructions

BEFORE EACH START UP

1. Press the ON/OFF switch down to the off position.
2. Turn the air pressure regulator knob (D) counterclockwise until it stops.
3. Attach air hose/accessories or air tools (not included) to the airline outlet (F).



WARNING!



Risk of bursting. Too much air pressure causes a hazardous risk of bursting. Check the manufacturer's maximum pressure rating for air tools and accessories. The regulator outlet pressure must never exceed the maximum pressure rating.

Note: Use this compressor in 20~30 degrees Celsius conditions.

HOW TO START UP

1. Close the air tank ball valve (G) by turning clockwise.
2. Plug in the mains lead.
3. Pull the ON/OFF switch UP to the on position and allow tank pressure to build. Motor will stop when tank pressure reaches "cut-out" pressure.
4. Turn the air pressure regulator (D) clockwise until desired pressure is reached.
5. The compressor is ready for use.




WARNING



High temperatures are generated by the electric motor and the pump. To prevent burns or other injuries,

- DO NOT touch the compressor while it is running.
Allow it to cool before handling or servicing.
- Keep children away from the compressor at all times.
When adjusting from a higher to a lower pressure, Turn the knob counterclockwise past the desired setting.
Then turn clockwise to reach the desired pressure.


- Do not exceed operating pressure of the tool or accessory being used.




HOW TO SHUT DOWN


1. Press the ON/OFF switch down to the off position.
2. Unplug the mains lead.
3. Reduce the pressure in the tank through the outlet hose. Keep it open to reduce the pressure in the tank until empty.
4. Tip the compressor so the tank drain valve is at the bottom of the tank, then open the tank drain valve (G) to allow moisture to drain from the tank.

CAUTION!

 Escaping air and moisture can propel debris that may cause eye injury. Wear safety glasses when opening the drain valve.

WARNING!

 To avoid personal injury, always shut off and unplug the unit and relieve all air pressure from the system before performing any service on the air compressor.

 Risk of unsafe operation. Unit cycles automatically when power is on. When performing maintenance, you may be exposed to voltage sources, compressed air or moving parts. Personal Injuries can occur. Before performing any maintenance or repair, disconnect power source from the compressor and bleed off all air pressure.

Maintenance

WARNING:





To avoid personal injury, always shut off and unplug the unit and relieve all air pressure from the system before performing.

Regular maintenance will ensure trouble-free operation.

TASK	DESCRIPTION	SERVICE INTERVAL
Drain the tank	To prevent corrosion inside the tank, the condensation must be drained at the end of every workday. Be sure to wear protective goggles. Relieve the air pressure intersystem and then open the ball valve on the bottom of the tank.	Daily
Test for leakage	Check all connections to see if tight. A small leak of any of part (the tank, hoses, pipe connections or transfer tubes) will reduce the unit's performance. Spray a small amount of soapy water around the area of the suspected leak with a spray bottle. If bubbles appear, repair or replace the faulty component. Do not overtighten any connections.	Monthly
Nuts & Bolts / stability Check	Check nuts & bolts regularly. Check that the wheels and handle fixings are secure & that the compressor is stable.	Monthly
Storage	Before storing the unit for a long period, use an air blow gun to clean all dust and debris from the compressor. Disconnect and coil the power cord. Pull the drain valve valve to release all pressure from the tank. Drain all moisture from the tank. Cover the entire unit to protect it from moisture and dust.	N A

Troubleshooting

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Low pressure, not enough air or compressor does not stop	<ol style="list-style-type: none"> 1. Tank drain valve is open. 2. Fittings leak. 3. Prolonged or excessive use of air . 4. Compressor not large enough. 5. Hole in air hose. 6. Tank leaks. 7. Blown seals. 8. Valve leaks. 9. Leaking or worn piston. 	<ol style="list-style-type: none"> 1. Close tank drain valve. 2. Check fittings with soapy water. Tighten or reseal leaking fittings. DO NOT OVER TIGHTEN. 3. Decrease amount of air used. 4. Check air requirement of accessory. If it is higher than LPM and pressure supplied by compressor, you need a larger compressor. Most accessories are rated at 25% of actual LPM while running continuously. 5. Check and replace if necessary. 6. WARNING: Immediately replace tank. DO NOT attempt to repair.   7. Contact SIP (Industrial Products) Ltd. 8. Contact SIP (Industrial Products) Ltd. 9. Contact SIP (Industrial Products) Ltd
Air leaks from regulator, or regulator does not regulate pressure	<ol style="list-style-type: none"> 1. Dirty or damaged regulator internal parts. 	<ol style="list-style-type: none"> 1. Replace regulator.
Regulated pressure gauge reading drops when air accessory is being used	<ol style="list-style-type: none"> 1. This is normal. 2. Compressor not large enough. 	<ol style="list-style-type: none"> 1. If pressure drops to low, adjust regulator while accessory issued. 2. Check air requirement of accessory. If it is higher than LPM and pressure supplied by compressor, you need a larger compressor. Most accessories are rated at 25% of actual LPM while running continuously.
Pressure relief valve opens	<ol style="list-style-type: none"> 1. Tank pressure exceeded normal rating pressure. 2. Pressure switch stuck. 	<ol style="list-style-type: none"> 1. Replace pressure switch. 2. Replace pressure switch.


<p>Motor will not run</p>	<ol style="list-style-type: none"> 1. Tank pressure exceeds preset pressure switch limit. 2. Fuse blown or circuit breaker tripped. 3. Check valve is stuck open. 4. Extension lead wire gauge too small or lead is too long. 5. Loose electrical connections. 6. The motor's thermal overload protection has tripped. 7. Theodor, capacitor or safety valves defective. 	<ol style="list-style-type: none"> 1. Motor will start automatically when tank pressure drops below tank cut-in pressure. 2. Replace blown fuse or reset circuit breaker. Do not use fuse or circuit breaker with higher rating than specified for your branch circuit. • Check for proper fuse; 13A is required for the plug • Check for low voltage and proper extension cord size. • Disconnect other applications from circuit. Operate compressor on a dedicated circuit. 3. Remove and clean or replace. 4. Check for proper gauge and extension cord length. 5. Contact authorized service center. 6. Turn the air compressor off, unplug the power cord and wait until the motor has cooled down. Plug in the power cord only after the motor has cooled down, waiting at least five minutes to make sure the thermal overload protector has recovered. 7. Have the compressor serviced by a qualified technician.
---------------------------	---	--

Technical Specification

Model	04381 QT 24/10
Supply	230v 50Hz
Motor Power	1.3HP / 1KW
Motor Poles / Speed	4 / 1400rpm
Pump	Oil – Less
Piston Displacement	7.3ft ³ /Min – 208Litres/Min
Free Air Delivered	5.4ft ³ /Min -153Litres/Min
Maximum Pressure	10Bar – 145psi
Receiver Size	24Litres
Noise	59dB(A) LA 73dB(A)LA

Model	04382 QT 50/10
Supply	230v 50Hz
Motor Power	1.3HP / 1KW
Motor Poles / Speed	4 / 1400rpm
Pump	Oil – Less
Piston Displacement	7.3ft ³ /Min – 208Litres/Min
Free Air Delivered	5.4ft ³ /Min -153Litres/Min
Maximum Pressure	10Bar – 145psi
Receiver Size	50Litres
Noise	59dB(A) Lapa 73dB(A)LA


Exploded View 04381



Parts List 04381

Item	Description	Qty	Item	Description	Qty
1	Air Filter	1	19	Drain Valve	1
2	Delivery Pipe	1	20	Screw M5 x 20	2
3	Motor Pump Unit	1	21	24Litre Air Receiver	1
4	Elbow Connector	1	22	Non Return Valve	1
5	Bleed Pipe	1	23	Nut M10	2
6	Pressure Safety Valve	1	24	Spring Washer 10mm	2
7	Pressure Switch	1	25	Wheel	2
8	Mains Lead	1	26	Wheel Axle	2
9	Receiver Pressure Gauge	1	27	Crimp Connector	2
10	Equal Connector	1	28	Capacitor	1
11	Working Pressure Gauge	1	29	Capacitor Retaining Ring	2
12	Air Pressure Regulator	1	30	Self Tapping Screw 4.8x 14	2
13	Quick Coupler	1	31	Capacitor Cover	1
14	Handle	1	32	Cable Clamp	1
15	Wing Nut	2	33	Self Tapping Screw 3.9 x 14	2
16	Receiver Bung	2	34	Nut M6	4
17	Rubber Foot	2	35	Rubber Mount	4
18	Washer 10mmØ	2	36	Air Filter Tube	1

Exploded View 04382



Item	Description	Qty	Item	Description	Qty
1	Receiver Bung	2	19	Air Filter Tube	1
2	Nut	4	20	Rubber Mounts	4
3	Wing Nut	2	21	Capacitor Cover	1
4	Non Return Valve	1	22	Capacitor Cover Screws	2
5	Handle	1	23	Capacitor Retaining Ring	2
6	Bleed Pipe	1	24	Capacitor	1
7	Mains Lead	1	25	Crimp Connector	2
8	Air Pressure Regulator	1	26	Self Tapping Screw 3.9 x 14	2
9	Quick Coupler	1	27	Cable Clamp	1
10	Working Pressure Gauge	1	28	Wheel Axle	2
11	Receiver Pressure Gauge	1	29	Wheel	2
12	Pressure Safety Valve	1	30	Axle Washer	2
13	Pressure Switch	1	31	Axle Nut	2
14	Equal Connector	1	32	50Litre Air Receiver	1
15	Delivery Pipe	1	33	Drain Valve	1
16	Elbow Connector	1	34	Rubber Foot Washer	2
17	Motor Pump Unit	1	35	Rubber Foot Bolt	2
18	Air Filter	1	36	Rubber Foot	2

EC DECLARATION OF CONFORMITY

We
 SIP (Industrial Products) Ltd
 Gelder's Hall Road
 Shepshed
 Loughborough

Leicestershire
LE12 9NH
England

As The Manufacturer's Authorized Representative
Declare that the

SIP QT 24/10 Air Compressor – SIP Part No. 04381

SIP QT 50/10 Air Compressor – SIP Part No. 04382

Conforms to the requirements of the following Directive/s, as indicated.

2014/30/EU 2006/42/EC 2000/14/EC 2014/68/EU 2011/65/EU	The Electromagnetic Compatibil The Machinery Directive Noise Emission Directive Pressure Equipment Directive RoHS Directive
--	---

Noise measurements have been made in accordance with the internal control of production (Schedule 45/Annex V). The declared noise values are as follows:

Measured Sound Power Level 59dB(A)

Guaranteed sound power level 73dB(A)

And the relevant harmonised standard/s, including:

EN 60204-1:2018

EN 1012-1:2010



EN 55014-1:2017

EN 55014-2:2015

EN61000-3-2:2014

EN61000-3-3:2013

EN ISO 3744:2010

Name: Mr. Paul Ipsos

Position: Director

Date: 08/10/2020



Please dispose of packaging for the product in a responsible manner. It is suitable for recycling. Help to protect the environment, take the packaging to the local amenity tip and place into the appropriate recycling bin.



Never dispose of electrical equipment or batteries in with your domestic waste. If your supplier offers a disposal facility please use it or alternatively use a recognized re-cycling agent. This will allow the recycling of raw materials and help protect the environment.



SIP INDUSTRIAL

FOR HELP OR ADVICE ON THIS PRODUCT PLEASE CONTACT YOUR DISTRIBUTOR, OR


SIP DIRECTLY ON:

TEL: 01509500400

EMAIL: sales@sip-group.com or technical@sip-group.com

www.sip-group.com

Documents / Resources

 <p>SIP SIP QT Air Oil-Less Air Compressors</p> <p>IP 04381 QTA24 10 SIP QT Air Oil Less Air Compressors</p>	<p>SIP INDUSTRIAL 04381 QTA24/10 SIP QT Air Oil Less Air Compressors [pdf] User Manual 04382, QTA50 10, 04381, QTA24 10, 04381 QTA24 10, SIP QT Air Oil Less Air Compressors, 04381 QTA24 10 SIP QT Air Oil Less Air Compressors, Oil Less Air Compressors, Air Compressors, Compressors</p>
---	--

References

- [G Group Publishing](#)
- [SIP Industrial Products Ltd Official Website - SIP Industrial Products Ltd Official Website](#)

Manuals+